


R



All manufacturer's names, numbers, photos, product description and/or part numbers are used for reference purposes only & it is not implied that any part listed is the product of these manufacturers. Since Approvement are made from time to time, the illustration and specifications are subject to change without notice.



10. FIRST & SECOND STAGE DISCHARGE VALVE ASSEMBLY Parts For Compressor

No.	Description	Ref Part No.	QTY
-	Discharge Valve Assembly	Z2570196	1
1	*Valve Seat Assembly	Z2566196	1
2	*Valve Keeper	C6182196	1
3	*Damper Plate	E2230196	2
4	*Valve Plate	-	1
5	*Valve Spring	-	8
6	*Lift Washer - Middle	H0811196	1
7	*Lift Washer - Upper	H0809196	1
8	*Split Pin	M5109170	1
-	*'O'Ring For Valve Cover	H0221170	1
-	*Copper Gasket	M3637170	1
-	Valve Cover	C0222164	1
-	Valve Service Kit	Z2578196	-

All manufacturer's names, numbers, photos, product description and/or part numbers are used for reference purposes only & it is not implied that any part listed is the product of these manufacturers. Since Approvement are made from time to time, the illustration and specifications are subject to change without notice.