



All manufacturer's names, numbers, photos, product description and/or part numbers are used for reference purposes only & it is not implied that any part listed is the product of these manufacturers. Since Approvement are made from time to time, the illustration and specifications are subject to change without notice.

7. SUCTION VALVE AND COVER ASSEMBLY (for 320 & 370 Cylinder)



No.	Description	Ref Part No.	QTY
-	Suction valve Assembly	1903256890	1
1	Guide nut for Lifter	M2081163	1
2	`O' Ring	H0221150	1
3	`O' Ring for piston Dia. 35	H0210150	1
4	Piston for Regulation	B0903164	1
-	Suction Valve cover Assly.(for HN2T 120/150LP)	Z2558164	1
-	Suction Valve cover Assly.(for HN2T 180/215LP)	Z2557164	1
5	Suction Valve cover	-	1
6	Sleeve Dia. 35	C6567160	1
7	Piston Dia. 35	B0902164	1
8	Circlip Dia. 40	M4009164	1
9	Washer	M3638150	1
10	Copper Washer	M3637150	1
11	Lock for Screw	M3840164	1
-	Hex Head Screw	M2645150	4
12	Castle Nut	M2221160	1
13	Spring	H3483164	1
14	Split Pin Dia. 2.5	M5108150	1
15	Lifter	C9007164	1
16	Suction Valve	1903256890	1
	Valve Service Kit	1903005595	
-	Valve Plate	E2229164	1
-	O ring for Unloading piston	H0210150	1
-	O ring for Valve Holder	H0221150	1
-	Lift Washer Top	H0808164	1
-	Lift Washer Bottom	H0809164	1
-	Valve Spring	H3486164	8
-	Cu. Washer	M3637150	1
-	Split Pin	M5109150	1
-	O ring	H0219150	1

Note :-

Suction Valve Assembly - Qty, : 04nos. per Compressor (for HN2T 120/150LP) Suction Valve Assembly - Qty, : 06nos. per Compressor (for HN2T 180/215LP)

All manufacturer's names, numbers, photos, product description and/or part numbers are used for reference purposes only & it is not implied that any part listed is the product of these manufacturers. Since Approvement are made from time to time, the illustration and specifications are subject to change without notice.